- [Minus] Command

This page describes the syntax and how to use the - [Minus] command.

Description

With the - [Minus] command you can:

- Deselect objects from a selection list
- Reduce the dimmer value
- Call the previous page

Syntax

1. Remove objects from a list:

- 5

2. Reduce dimmer values:

At - 12

3. Call previous page:

Page -

The - [Minus] command is a helping command and needs a second command or a number.

Example 1

Let´s assume, you have a long selection list with fixtures and you will deselect one of them.

Figure 1: All fixtures selected

- Press **-** **5** **Please** on the console.

The fixture ID 5 is removed from the selection list.

Figure 2: Fixture 5 is removed from the selection list

Example 2

Let´s assume, you have a long selection list with fixtures and you will deselect fixture ID 5 thru 7.

Figure 3: All fixtures selected

- Press `-` `5` `Thru` `7` `Please` on the console.

The fixture ID 5 thru 7 are removed from the selection list.

Figure 4: Fixture 5 thru 7 are removed from the selection list

Example 3

Let´s assume, you will reduce the dimmer value by 12 % from selected fixtures.

Figure 5: Dimmer at 50

- Press `At` `-` `12` `Please` on the console.

The dimmer values are reduced by 12 %.

Figure 6: Dimmer reduced by 12%

> **Hint:**
> To reduce the dimmer value by 10 %, press the `-` key twice.

Example 4

Let´s assume, you will call the previous page

- Press `Page` `-` `Please` on the console.

The previous page opens.