



## Backup key

Pressing the **Backup** key will open and close the [Backup Window](#) on screen 1.

Here you can create a new show, load a saved show, save your current show and save your current show with a new name.

If you press the key fast twice (like a double click) you will save your show immediately. This can only be done if you *don't* have the backup menu open.

If you have a USB memory stick in the console then it will also store your show to the stick.

## Quick Save

A fast double press on the **Backup** key will save your current show. This only works if you don't have the Backup Window open when you do the double press.

## Related Links

[Backup Window](#)

[How to save and load your show](#)