

## ChangeDest keyword

To execute this keyword type **ChangeDest** or one of the shortcuts – **CD** or **Chang** – into the command line.

### Description

**ChangeDest** is a function used to change the destination of your command line.

### Syntax

CD [Element-index]

CD "Element name"

CD [Object-type] [Object-ID]

CD ..

CD /

Changing the destination is done by drilling down through a tree-structured database. To display the elements at a given destination use the function List.

For more information on the function List see [List](#).

### Example:

A dark green rectangular bar with a yellow sphere icon on the left. The text inside the bar is "[Channel] > CD 3".

[Channel] > CD 3

Enters the 3rd element of the current destination:

A dark green rectangular bar with a yellow sphere icon on the left. The text inside the bar is "Settings 3 >".

Settings 3 >

A dark green rectangular bar with a yellow sphere icon on the left. The text inside the bar is "[Channel] > CD \"Edit Setup\"".

[Channel] > CD "Edit Setup"

Enters the element of the current destination named "Edit Setup":

A dark green rectangular bar with a yellow sphere icon on the left. The text inside the bar is "Edit Setup >".

Edit Setup >

 [Channel] > CD Group

Enters the predefined destination Groups:

 Groups/Global >

 Edit Setup/Universes > CD ..

Exits one level up in the tree structure:

 Edit Setup >

 Edit Setup/Universes > CD /

Exits all levels up the root (no destination):

 [Channel] >