

System Requirements grandMA2 onPC

If you want to run the grandMA2 onPC your PC, here's what it takes.

Туре	Minimum	Recommended
Operation	Windows® 7	
system		
	Windows® 8	
	Windows® 8.1	
	Windows® 10	
	all with admin rights	
Processor	CPU Dual Core 2.4 GHz or faster	
	with SSE2 support	
RAM	2 GB	8 GB
Hard disk	32 GB available space	type SSD
Graphic card	Any graphic card with hardware acceleration and 512	
	MB	
Resolution	1600 x 900 or higher	1920 x 1080
Network card	100BASE-TX, 1000BASE-T	1000BASE-T

IBM® compatible PC or notebook is necessary.

Additional requirements:

- Make sure your Windows® always runs using the latest service pack and updates.
- To save a grandMA2 show file as a grandMA3 show file, Windows® 10 is required. For more information see <u>Save as grandMA3</u>.
- To use the online help and to download the latest version of grandMA2 onPC, you need internet access.
- To save to a USB stick, you need a USB 2.0 or 3.0 port.

We recommend that you visit your PC manufacturer's website for information about updated drivers and hardware compatibility.