



## UpdateSoftware Keyword

To go to the UpdateSoftware keyword, type **UpdateSoftware** in the command line or use the shortcut **UpdateS**.

You can also update the software in the Setup. For more information, see [update the software](#).

## Description

### Requirement:

An inserted USB stick with a .update file for the appropriate device or program in the root directory.

Download the latest software on [www.malighting.com](http://www.malighting.com).

With the UpdateSoftware keyword, you can update the software of every MA device or program in the network.

The UpdateSoftware keyword is a function keyword.

## Syntax

**UpdateSoftware [IP address]**

## Example

Update the MA 4Port Node with the IP address 192.168.0.32 in the network.

 [Channel]> UpdateSoftware 192.168.0.32

### Hint:

To be faster, type only the part of the IP address in the command line what is differently.

If the console which sends the command has the IP address 192.168.0.11, then type **UpdateSoftware 32**.