



## Go- | Top key

Pressing **Go-** enters the Go-keyword into the command line.



For more information about Go-, see the **Go- keyword** topic.


## Top

Pressing and holding **MA** + **Go-** enters the Top keyword into the command line.




For more information about Top, see the **Top keyword** topic.

**Go-** is located in the command section.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing