



Copy Keyword

To enter the Copy keyword in the command line, use one of these options:

- Press **Copy**
- Type **Copy**
- Type the shortcut **Co**

Description

The Copy keyword is a function keyword used to create copies of an object.

If no object type is given and the command line destination is root (no destination), the default object type – **Cue** – is used for this function.

Syntax

Copy [Object] At [Target ID]

Copy [Object List] At [Target Start]

Copy [Object] At [Target List]

Copy [Object List]

Examples

- To copy group 1 to group 5, type:

```
MA User name[Fixture]> Copy Group 1 At 5
```


- To copy group 1 to group 11; group 2 to group 12; and group 3 to group 13, type:

```
MA User name[Fixture]> Copy Group 1 Thru 3 At 11
```

- To copy group 2 to group 6, 7, and 8, type:

```
MA User name[Fixture]> Copy Group 2 At 6 Thru 8
```

- Copies cue 2 to cue 6 of the selected sequence, type:

 User name[Fixture]> Copy 2 At 6

- To copy macro 2 to macro 6, type:

 User name[Fixture]> Copy Macro 2 At 6