

## Station List

Syntax

[IP-address]

[IP-address] Thru [IP-address]

[Host-ID]

[Host-ID] Thru [Host-ID]



## Important:

The **IP address** is a 32-bit dotted decimal notation consisting of four numbers ranging from 0 to 255 and separated by dots, for example 192.168.0.101.

- The **host ID** is a unique part of the IP address within a network. The host ID usually comprises the last three decimal numbers of the IP address. The host ID of the IP address 192.168.0.101 is 101 and the network ID is 192.168.0.
- If the beginning or the end of the command Thru is missing, the first or the last occurrence will be used.

## Example:



[Channel] > SetIP ethO 192.168.0.101

Sets the IP address.



[Channel] > Shutdown 1 Thru 4

Shuts down all the devices with the host IDs 1, 2, 3, and 4.

For more information on how to set the IP address see <u>SetIP</u>.