




Blind key

Pressing **Blind** executes the Blind keyword in the command line. It toggles Blind on and off.




For more information about Blind, see the **Blind keyword** topic.

Blind is located in the Command Section.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing