


Full key

Pressing **Full** enters the Full keyword into the command line. The dimmer values for the selected fixtures sets to 100%.




For more information about Full, see the [Full keyword](#) topic.

Full is located in the command section.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing