



SnapDelay Keyword

To enter the SnapDelay keyword in the command line, use one of the options:

- Type **SnapDelay**
- Type the shortcut **Sn**

Description

The SnapDelay keyword sets a snap time.

The snap time is a delay time for attributes that do not fade, for example a gobo wheel or a color wheel.

Syntax

SnapDelay [Value]

Examples

- To set the snap time of the current cue of the selected sequence to 4 seconds, type:

```
MA User name[Fixture]> SnapDelay 4
```