


Page- key

Pressing **Page-** executes the command Previous Page in the command line.


OK:Previous Page

Pressing and holding **Page-** for more than 1 second sets the page to page 1.

Page- is located in the command section.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing