



Down key

Pressing **Down** goes one level down in the fixture structure.

Down is located in the command section on the left side of the five dual encoders.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing