



grandMA3 full-size



grandMA3 full-size front panel

1. **Screens 1-3**
2. **Letterbox screens 8-10**
3. **Command screens 6+7**
4. **Power key**
5. **Level wheel**

6. **Command section**
7. **Xkeys**
8. **Master section**
9. **Right executor section**
10. **Custom section**
11. **Left executor section**



grandMA3 full-size rear panel

1. **Desk light**
2. **powerCON TRUE1**
3. Power switch
4. **DMX A-G**
5. **DisplayPort 4+5**
6. **LTC**
7. **USB 3.0**
8. **Audio Remote In**
9. **DC Remote Control**
10. **Ethernet 1-3**
11. **S/PDIF In+Out**
12. **USB 2.0**
13. **MIDI In+Out**



Hint:

To display the rear panel connectors on the letterbox screens, type:



User name[Fixture]> Menu "Connectorview"

For technical specifications, see **Technical Data** in the **grandMA3 Quick Manual consoles**.