



grandMA3 light



grandMA3 light front panel

1. **Screens 1+2**
2. **Letterbox screens 8+9**
3. **Command screens 6+7**
4. **Power key**

5. Level wheel
6. Command section
7. Xkeys
8. Master section
9. Executor section



grandMA3 full-size rear panel

1. Desk light
2. powerCON TRUE1
3. Power switch
4. DMX A-G
5. DisplayPort 4+5
6. LTC
7. USB 3.0
8. Audio Remote In
9. DC Remote Control
10. Ethernet 1-3
11. S/PDIF In+Out
12. USB 2.0
13. MIDI In+Out



Hint:

To display the rear panel connectors on the letterbox screens, type:



User name[Fixture]> Menu "Connectorview"

For technical specifications, see **Technical Data** in the **grandMA3 Quick Manual consoles**.