


Please key

Pressing **Please** executes the command in the command line. This is the same function as pressing **Enter** on an external keyboard.


Activate all Attributes

- Pressing **Please Please** activates all attributes of the selected fixtures.
- Pressing **Please** once more deactivates all attributes of the selected fixtures.

Please is located in the numeric keys section.



Location on grandMA3 full-size and grandMA3 light consoles



Location on grandMA3 compact consoles and grandMA3 onPC command wing