


Command Wing Bar


The **Command Wing Bar** combines a small version of the **Playback Bar**, including two sections of executors and the **Master Area**, with a compressed version of the **Encoder Bar**. This combined bar is helpful for optimizing screen space and minimizing the views necessary to move between programming and playback, especially when using the grandMA3 onPC software. The executors displayed on the playback side of the bar coincide with the executor sections available on the grandMA3 onPC command wing and command wing XT.

In the grandMA3 onPC software, tap the  icon in the **Control Bar** to toggle the **Encoder Bar** to the **Command Wing Bar**. The **Command Wing Bar** is also available as a window under the **More** and **All** tabs in the **Add Window** pop-up. For more information on adding windows, see the [Add Window](#) topic.



Command Wing Bar

Tap **MA** in the upper-left corner of the **Command Wing Bar Window** to access the **Command Wing Bar Window Settings** pop-up.



Command Wing Bar Window Settings pop-up

This pop-up includes the following settings:

- **Display Mode Executors**: Tap to toggle the display of the executors in the window between **Labels** and **Hardware Buttons**.



- **Display Mode Masters** : Tap to toggle the display of the special masters in the window between **Labels** and **Hardware Buttons**.

The **Window Settings** topic describes additional window settings.