



Full Keyword



Important:

Pressing **Full** directly executes the keyword.

To enter the **Full** keyword in the command line, use one of the options:

- Type **Full**
- Type the shortcut **Fu**

Description

Full is a function keyword used to set the dimmer values to 100 %.

The default function is At. This means that entering Full sets the dimmer attributes of the current selection to 100 %.

Syntax

Full

Example

- To select fixture 1 thru 10 and set the dimmer to 100 %, type:



```
User name[Fixture]> Fixture 1 Thru 10 Full
```

- To select channel 53 and set the dimmer to 100 %, type:



```
User name[Fixture]> Channel 53 Full
```