




grandMA3 onPC command wing



grandMA3 onPC command wing front panel

1. **Master area**
2. **Dual encoder section**
3. **Command area**
4. **Level wheel**
5. Executor buttons 101-190 + 201-290
6. Executor faders 201-290
7. Executor buttons 301-390 + 401-490
8. Executor knobs 301-390 + 401-490

For more information about executors, see **Executor elements**.



grandMA3 onPC command wing rear panel

1. **DMX A, B, C**
2. **MIDI In+Out**
3. **DC Remote Control**
4. **LTC**
5. USB
6. Power switch
7. **IEC connector**
8. **Desk light**
9. Kensington lock

For technical specifications see **Technical Data** in the **grandMA3 Quick Manual onPC command wing**.