

## SendMIDI Keyword



**Important:**

If you do not define a channel value, the MIDI messages will be automatically addressed to channel 1.

To enter the SendMIDI keyword in the command line, use one of the options:

- Type **SendMIDI**
- Type **Sendm**

## Description

The SendMIDI keyword is a command keyword that is used to output MIDI notes, MIDI control change messages, and MIDI program change messages.

## Syntax

SendMIDI "Note" (Channel/)Note (Velocity) (Status)

SendMIDI "Program" (Channel/)Value

SendMIDI "Control" (Channel/)Controller (Value)

## Examples

- To send out the MIDI note 42 on MIDI channel 2 with a velocity of 99, type:

```
MA User name[Fixture]> SendMIDI "Note" 2/42 99
```

- To send out the MIDI note 37 on MIDI channel 1, type:

```
MA User name[Fixture]> SendMIDI "Note" 37
```

- To send out the MIDI control value 64 to MIDI channel 1 controller 8, type:

```
MA User name[Fixture]> SendMIDI "Control" 1/8 64
```

- To send out a MIDI program change of 12, type:



```
MA User name[Fixture]> SendMIDI "Program" 12
```