


## Go- [large] Key

Go- Executor is executed immediately in the command line when pressing **Go-** [large].


OK : Go- Executor

For more information about Go-, see the **Go- keyword** topic.

**Go-** [large] is located in the master section under the two master faders.



*Location on grandMA3 full-size and grandMA3 light consoles*



Location on grandMA3 compact consoles and grandMA3 onPC command wing