



Keyboard shortcuts



Important:

- 1. Keyboard shortcuts are only available on a grandMA2 onPC.
 - 2. Keyboards that have a different keyboard layout, as opposed to German keyboards, do not support all default keyboard shortcuts.
- If this should be the case with your keyboard, adjust the shortcuts affected. To transfer these to other show files and/or stations, use the Import/Export function. For more information on how adjust the shortcuts see [export or import keyboard shortcuts](#).

The go to the keyboard shortcuts press the **Setup** and under tab **Console** tap **Edit Keyboard Shortcuts**.

Edit Keyboard Shortcuts

Predefined Shortcuts: (Shortcuts currently available for onPC only)

- <Shift>: Hardware Button MA
- <Insert>: Toggle between shortcut and normal mode
- <Ctrl> + Digits[0..9]: Fader Executor Buttons (Top) while releasing <Ctrl>
- <Alt> + Digits[0..9]: Fader Executor Buttons (Middle) while releasing <Alt>
- <Ctrl> + <Alt> + Digits[0..9]: Fader Executor Buttons (Bottom) + Button Executors while releasing <Ctrl>

Direct Access

Hardkey	PCkey
0	0
1	1
2	2
3	3
4	4
5	5

Ctrl Access

Hardkey	PCkey
Go +	<
Align	A
B.O.	B
Copy	C
Delete	D
X 11	F1

Alt Access

Hardkey	PCkey
Assign	A
Backg	B
Cue	C
Effect	E
Freeze	F
U1	F1

Ctrl Alt Access

Hardkey	PCkey
Backup	B
Encoder	E
Fix	F
Go -	G
Help	H
Preview	P

Add

Delete

Import

Export

Reset to Defaults

Edit Keyboard Shortcuts window

The following tables displays the default grandMA2 onPC keyboard shortcuts.

Shortcuts for command area keys

Key	Shortcut
Blind	B
Freeze	Alt + F
Prevw	Ctrl + Alt + P
Assign	Alt + A
Align	Ctrl + A



Key	Shortcut
U1	Alt + F1
U2	Alt + F2
U3	Alt + F3
U4	Alt + F4
Fix	Ctrl + Alt + F
Select	Ctrl + S
Off	O
Temp	Ctrl + Alt + T
Top	Alt + T
On	Ctrl + O
<<<	Alt + <
Learn	Ctrl + L
>>>	Ctrl + Alt + <
Small Go -	<
Small Pause	Ctrl + P
Small Go +	Ctrl + >
View	V
Effect	Alt + E
Goto	Alt + G
Page	Alt + P
Macro	M
Preset	P
Sequ	Alt + S
Cue	Alt + C
Exec	X
Channel	C
Fixture	F
Group	G
Delete	Ctrl + D
Move	Ctrl + M
Copy	Ctrl + C
Full	Ctrl + F
Hightl	H
Solo	Ctrl + Alt + S
Backg	Alt + B
User1	Ctrl + U
User2	Alt + U
Time	Ctrl + T
Esc	Esc
Edit	E

Key	Shortcut
Oops	Backspace
Update	U
Clear	Delete
List	L
Store	S
MA	Shift
Please	Enter
.	.
If	I
At	A
Thru	/ (number pad)
+	+
-	-
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Up	Arrow up
Down	Arrow down
Prev	Arrow left
Next	Arrow right
Set	End
⊙	Ctrl + Alt + E

Shortcuts for menu keys

Key	Shortcut
Tools	Ctrl + F12
Setup	F12
Backup	Ctrl + Alt + B
Help	Ctrl + Alt + H

Shortcuts for X-keys

Key	Shortcut
X1	F1
X2	F2
X3	F3
X4	F4
X5	F5
X6	F6
X7	F7
X8	F8
X9	F9
X10	F10
X11	Ctrl + F1
X12	Ctrl + F2
X13	Ctrl + F3
X14	Ctrl + F4
X15	Ctrl + F5
X16	Ctrl + F6
X17	Ctrl + F7
X18	Ctrl + F8
X19	Ctrl + F9
X20	Ctrl + F10

Shortcuts for master section keys

Result	Shortcut
Ch Pg+	Alt + PgUp
Ch Pg-	Alt + PgDown
Fd Pg+	PgUp
Fd Pg-	PgDown
Bn Pg+	Ctrl + PgUp
Bn Pg-	Ctrl + PgDown
Large Pause	Alt + Space
Large Go-	Ctrl + Space
Large Go	Space

Shortcuts for grandMA2 onPC screen buttons

Result	Shortcut
Extern 1	Ctrl + Alt + F5
Extern 2	Ctrl + Alt + F6
Executor 1 - 15, 101 - 115	Ctrl + Alt + F7
Executor 16 - 30, 116 - 130	Ctrl + Alt + F8



Result	Shortcut
Screen 2	Ctrl + Alt + F2
Screen 3	Ctrl + Alt + F3
Screen 4	Ctrl + Alt + F4

Reset keyboard shortcuts to defaults

To reset the keyboard shortcuts to their defaults:

1. Click **Setup** and then under tab **console** click **Edit Keyboard Shortcuts**.
The Edit Keyboard Shortcuts window opens.
2. Click **Reset to Defaults**.

The keyboard shortcuts are reset to their defaults.