dot2 User Manual – Introduction Version 1.9 – 2025-05-07 English



## System Requirements dot2 onPC

If you want to run the dot2 onPC on your PC, here's what it take.

	Minimum	Recommended
Operating system	Windows® 7 Windows® 8 Windows® 8.1 Windows® 10 all with admin rights	
Processor	CPU Dual Core 2.4 GHz or faster with SSE2 support	
RAM	2 GB	4 GB
Hard disk	32 GB available space	type SSD
Graphic card	Any graphic card with hardware acceleration and 512 MB	
Resolution	1920 x 1080 Full HD	
Network card	100BASE-TX, 1000BASE-T	1000BASE-T

IBM® compatible PC or notebook necessary.

Additional requirements to use certain features:

- To use Art-Net with a dot2 onPC and Windows® 8 or Windows® 8.1, it is necessary to start the application as administrator.
- To change settings like the system clock, you need admin rights on your Windows® system.
- To use the online help manual, you need internet access.

We recommend that you visit your PC manufacturer's website for info about updated drivers and hardware compatibility.