



System Requirements dot2 onPC

If you want to run the dot2 onPC on your PC, here's what it take.

| | Minimum | Recommended |
|------------------|--|-------------|
| Operating system | Windows® 7 Windows® 8 Windows® 8.1 Windows® 10 all with admin rights | |
| Processor | CPU Dual Core 2.4 GHz or faster with SSE2 support | |
| RAM | 2 GB | 4 GB |
| Hard disk | 32 GB available space | type SSD |
| Graphic card | Any graphic card with hardware acceleration and 512 MB | |
| Resolution | 1920 x 1080 Full HD | |
| Network card | 100BASE-TX, 1000BASE-T | 1000BASE-T |

IBM® compatible PC or notebook necessary.

Additional requirements to use certain features:

- To use Art-Net with a dot2 onPC and Windows® 8 or Windows® 8.1, it is necessary to start the application as administrator.
- To change settings like the system clock, you need admin rights on your Windows® system.
- To use the online help manual, you need internet access.

We recommend that you visit your PC manufacturer's website for info about updated drivers and hardware compatibility.